













- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning

MVL661...




G0 G Y M U ZC 00448A
 AC 24 V
 DC 20...30 V

- green ok
- grün ok
- vert ok
- verde ok
- Calibr.
- red 24 AC / DC error
- rot 24 AC / DC error
- rouge error
- rosso error






$V_{min.} 0 \dots 80\%$




ON	Y:	U and Y:	U:	k_{vg} :
	[mA]	2 ... 10 V	[mA]	63 %
	1	4 ... 20 mA	2	
OFF	[V]	0 ... 10 V	[V]	100 %
		0 ... 20 mA	3	4



Expansion



Suction



Load 50 ... 100 %



Load 10 ... 100 %