















de Montageanleitung
en Mounting instructions
fr Instructions de montage
it Istruzioni di montaggio


es Instrucciones de montaje
nl Montage-aanwijzing
da Monteringsvejledning
sv Monteringsinstruktion



QAW910


CE 0678




B

LR6 (AA) 1.5 V


①




②





③




④




⑤

**C**


①




②




③ a)



b)



④



⑤

**A**
2701Z06

③ ... ⑥