

**de** Montageanleitung  
**en** Mounting instructions  
**fr** Instructions de montage  
**sv** Monteringsinstruktion  
**nl** Montage-aanwijzing  
**it** Istruzioni di montaggio  
**fi** Asennusohje  
**es** Instrucciones de montaje

**no** Montasjeanvisning  
**da** Monteringsvejledning  
**pl** Instrukcja montażu  
**cs** Montážní list  
**sk** Návod na montáž  
**hu** Telepítési leírás  
**el** Οδηγίες Τοποθέτησης  
**sr** Uputstva za montažu

**hr** Uputstva za montažu  
**sl** Navodila za montažo  
**ro** Instrucțiuni de montare

74 319 0339 0



## RMZ791





74 669 0014 0




74 421 077 0



RMZ791



Maße in mm  
 Dimensions in mm  
 Dimensions en mm  
 Mått i mm  
 Maten in mm  
 Dimensioni in mm  
 Mitat mm  
 Dimensiones en mm  
 Mål i mm  
 Wymiary w mm  
 Rozměry v mm  
 Vylomit' prepážku  
 Méretek mm-ben  
 Διαστάσεις σε mm  
 Dimenzije u mm  
 Dimenzije u mm  
 Dimenzije v mm



de: Klemmlasche ausbrechen  
 en: Knock out clamp  
 fr: Mise en place des clips  
 sv: Bottenplattans  
   fästbygel bryts ut  
 nl: Klem uitbreken  
 it: Eliminare il fermo  
 fi: Irrota kiinnityskynsi  
 es: Enfrentar bastidor, separar  
   pestañas y atornillar  
 da: Laskeplade slås ud  
 pl: Wyjąć zaczepy  
 cs: Průchodky vylomit  
 sk: vylomiť prepážku  
 hu: Bevezetése kitörésen  
   keresztül  
 el: Επαφή εξουδετέρωσης  
   (knock out)  
 sr: Izvadi osigurač  
 hr: Izvadići osigurač

