




- de** Montageanleitung
- en** Mounting instructions
- fr** Instructions de montage
- sv** Monteringsinstruktion
- nl** Montage-aanwijzing
- it** Istruzioni di montaggio
- fi** Asennusohje
- es** Instrucciones de montaje
- da** Monteringsvejledning

QVE1900



DN	(mm)	Nr.	Q _{max.} (m ³ /h)	↻ m ³ /h ↻		↻ m ³ /h ↻	
				≤	≥	≤	≥
32	29 x 34	1	3.6	≤0,8	≥1.3	≤2.8	≥3.0
40	29 x 34	1	4.8	≤1,1	≥1.7	≤3.7	≥4.0
50	29 x 60	1+2	7.3	≤2,2	≥3.1	≤5.7	≥6.1
65	29 x 60	1+2	8.4	≤2,7	≥4.0	≤6.5	≥7.0
80	29 x 89	1+2+3	13.7	≤4,3	≥6.2	≤10.7	≥11.4
100	29 x 92	1+2+3+4	22.1	≤6,1	≥8.0	≤17.3	≥18.4
125	29 x 117	1+2+3+4	32.2	≤9,3	≥12.9	≤25.2	≥26.8
150	29 x 143	1+2+3+4	39.2	≤12,3	≥16.8	≤30.6	≥32.7
200	29 x 167	1+2+3+4	113	≤38,6	≥46.1	≤90.8	≥94.2



1592M03